



CHEMICAL MAINTENANCE CHEAT SHEET



1. Alkalinity

Adjust alkalinity first as it affets your hot tubs pH levels. This should be between 100 - 150 ppm.

Add sodium bisulfate to lower alkalinity or sodium bicarbonate to increase alkalinity levels.



2. Sanitise

Add a chlorine or bromine tablet floater, reducing the frequency you will need to add granular forms of sanitiser.



Maintain a level of ppm

3. pH Levels

pH levels are important to be kept at the correct level to ensure sanitiser can work effectiely and to prevent any skin/eye irritation.

Add sodium bisulfate to lower pH or sodium carbonate to raiswe pH levels.

